



ALERT SERVICE BULLETIN INDEX

NOTE

THIS INDEX IS A LIST OF ALERT SERVICE BULLETINS ISSUED. THIS INDEX DOES NOT IDENTIFY WHICH ALERT BULLETINS ARE ACTIVE OR INACTIVE.

THE ATA/CHAP. REF. COLUMN INDICATES THE MAINTENANCE AND/OR OVERHAUL MANUAL CHAPTER/S AFFECTED BY THE RESPECTIVE BULLETIN; OR, THE BULLETIN IS APPLICABLE TO A SERVICE INSTRUCTION (S.I.).

PROPRIETARY RIGHTS NOTICE

These data are proprietary to Bell Helicopter Textron, Inc. Disclosure, reproduction, or use of these data for any purpose other than helicopter operation is forbidden without prior written authorization from Bell Helicopter Textron, Inc.

Newly released Alert Service Bulletins can be viewed and printed by accessing our Service Directives website at www.bellcustomer.com. This publication supersedes BHT-206A/B/B3-ASB INDEX dated 1 January 2007 in its entirety.

COPYRIGHT NOTICE
COPYRIGHT 2008
BELL © HELICOPTER TEXTRON INC.
AND BELL HELICOPTER TEXTRON
CANADA LTD.
ALL RIGHTS RESERVED

Bell Helicopter
A Textron Company

POST OFFICE BOX 482 • FORT WORTH, TEXAS 76101

1 JANUARY 2008

206A/B/B3 ALERT SERVICE BULLETIN INDEX

STATUS CODE

A = Active

A- () = Active — (Additional Information)

└────────────────── P = Incorporated in Parts Catalog
R = Referenced in Maintenance Manual

I = Inactive

I- () = Inactive — (Reason)

└────────────────── I = Incorporated in Maintenance Manual
P = Incorporated in Parts Catalog
S = Superseded (New Bulletin Number)
R = Referenced in Maintenance Manual

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------|-----------------|--------------------|--------|------------------|--|
| 206A-1 | Basic | 10-10-67 | | VII | Engine Droop Compensator Safety Wire Provisions |
| 206A-2 | Basic | 10-16-67 | | IV | Cyclic Control System Inspection and Addition of Shield |
| 206A-3 | Basic | 10-25-67 | | VII | Exhaust Stack Clamp, Inspection and Safety Wiring |
| 206A-4 | Basic Rev. A | 11-8-67 1-20-68 | | VII | Engine Mount, Inspection and Addition of Support Bracket |
| 206A-5 | Basic | 11-9-67 | | IV | Tail Rotor Control, Addition of Friction Clamp, Spring and Support |
| 206A-6 | Basic | 11-10-67 | | IV | Cyclic and Collective Control Tubes, Inspection of |
| 206A-7 | Basic | 8-22-68 | | VIII | Magnesium Tail Boom, Inspection of |
| 206A-8 | Basic | 10-21-68 | | VI | Transmission Spider, Inspection and Retirement of |
| 206A-9 | Basic | 12-30-68 | | VI | Fan Shaft Assembly, Inspection |
| 206A-10 | Basic | 4-11-69 | | VI | Transmission Spindle, Inspection of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | SUBJECT |
|---------------|-----------------|----------------------|---------------|-----------------|---|
| | | | | REF. | |
| 206A-11 | Basic Rev. B | 5-9-69 9-29-69 | | IV | Cyclic Control Bellcrank Support, Replacement of |
| 206A-12 | Basic Rev. A | 7-25-69 4-8-70 | | V | Hydraulic Cylinder, P/N 41103750, 41103750-2, and 41103650-005, Retirement Life |
| 206A-13 | Basic | 8-4-69 | | IV | Dual Control, Lever Assy., Inspection of |
| 206A-14 | Basic Rev. C | 12-12-69 4-8-70 | | VI | Transmission Spider, Retirement of |
| 206A-15 | Basic | 12-19-69 | | VIII | Tail Rotor Gear Box and Tail Boom, Inspection of |
| 206A-16 | Basic | 3-3-70 | | S.I. | Snow Winterization Kit, Modification |
| 206A-17 | Basic | 9-10-70 | | VI | Installation and Inspection of Improved Magnetic Plug, Updating Transmission |
| 206A-18 | Basic | 11-19-70 | | VII | Aluminum Fuel Lines, Replacement of |
| 206A-19 | Basic Rev. C | 12-18-70 12-11-73 | | II | Main Rotor Blade Inspection |
| 206-20 | Basic Rev. A | 12-10-71 2-21-72 | | II | Strap, P/N 206-031-200-23 and -24, Inspection of |
| 206-21 | Basic Rev. A | 7-24-72 8-14-73 | | S.I. | Pop-Out Float System Valve Assy., Functional Check Procedure of |
| 206-22 | Basic | 10-25-72 | | IV | Idler Assy., P/N 206-001-746-5, Inspection and Rework |
| 206-23 | Basic | 11-13-72 | | VI | Main Rotor Mast Inspection |
| 206-24 | Basic | 11-21-72 | | II | Nuts, P/N NAS1022A14, Inspection of |
| 206-25 | NEVER ISSUED | | | | |
| 206-26 | Basic | 12-18-72 | | VIII | Vertical Fin, Inspection of |
| 206-01-73-1 | Basic | 1-9-73 | | VIII | Vertical Fin, Inspection of |
| 206-01-73-2 | Basic Rev. A | 3-9-73 3-27-73 | | VIII | Pylon Support Link, Inspection of |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | SUBJECT |
|-----------------|-----------------|----------------------|--------|----------|---|
| | | | | REF. | |
| 206-01-73-3 | Basic Rev. B | 4-12-73 10-23-73 | | VIII | Removal of Metal Plug Buttons |
| 206-01-73-4 | Basic Rev. B | 4-16-73 10-16-73 | | VIII | Tailboom Skin Splice Rivets, Inspection of |
| 206-01-73-5 | Basic Rev. A | 6-27-73 9-21-73 | | VIII | Vertical Fin Support, Inspection and Replacement of |
| 206-01-73-6 | Basic | 9-19-73 | | VIII | Pylon Support Links, P/N 206-031- 508-5 and -7, Retirement of |
| 206-01-73-7 | Basic Rev. E | 11-16-73 9-18-74 | | VIII | Horizontal Stabilizers, Inspection and Rework of |
| 206-03-73-1 | Basic Rev. C | 10-19-73 2-25-75 | | XI | Starter Generator Retaining Clamp "T" Bolt, Inspection and Replacement of |
| 206-04-73-1 | Basic | 8-8-73 | | VI | Tail Rotor Gear Inspection |
| 206-04-73-2 | Basic Rev. A | 11-13-73 10-21-75 | | VI | Restricted Use of Grease, P/N 204-040-755-3 |
| 206-(04-1)-73-1 | Basic | 6-25-73 | | II | Main Rotor Hub Strap Fittings and Pins, Retirement of |
| 206-(04-2)-73-1 | Basic | 5-7-73 | | IV | Main Rotor Pitch Link Tubes, Inspection of |
| 206-(04-2)-73-2 | Basic | 5-15-73 | | IV | Swashplate Bearing, Inspection of |
| 206-06-73-1 | Basic Rev. A | 4-27-73 6-26-73 | | V | Hydraulic Servo Actuator Piston Assy., P/N 41000005, Inspection and Rework of |
| 206-06-73-2 | Basic | 5-11-73 | | V | Hydraulic Servo Actuator Servo Valve Drive Locknut, Inspection of |
| 206-12-73-1 | Basic Rev. A | 6-26-73 7-19-73 | | S.I. | Heater Fuel Line Inspection |
| 206-50-73-1 | Basic | 1-16-73 | | S.I. | Heater Fuel Line Inspection |
| 206-50-73-2 | Basic Rev. A | 4-4-73 8-6-73 | | S.I. | Rotor Brake Disc Assy, Inspection of |
| 206-01-74-1 | Basic Rev. B | 4-17-74 6-4-74 | | VIII | Horizontal Stabilizer Stop, Kit Installation of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|-----------------|-----------------|---------------------|---------------|--------------------------|--|
| 206-01-74-2 | Basic | 11-12-74 | | VIII | Cabin Roof Straps, Mandatory Replacement of by 30 September 1975 |
| 206-01-74-3 | Basic | 10-16-74 | | VIII | Transmission Mount Spindle, Inspection of |
| 206-04-74-1 | Basic Rev. B | 6-25-74 10-8-74 | | VI | Tail Rotor Driveshaft Bearing Hanger Screws, P/N 206-040-323-1, Mandatory Replacement of |
| 206-(04-1)-74-1 | Basic Rev. A | 8-20-74 8-22-74 | | II | Main Rotor Hub Yoke, Inspection and Rework Mandatory by 31 December 1974 |
| 206-(04-1)-74-2 | Basic | 11-21-74 | | II | Main Rotor Grip Inspection |
| 206-(04-2)-74-1 | Basic | 6-20-74 | | IV | Cyclic and Collective Control System Attaching Bolts Mandatory Replacement by 30 July 1974 |
| 206-06-74-1 | Basic Rev. A | 9-6-74 10-8-74 | | V | Hydraulic Servo Actuators, Inspection of |
| 206-06-74-2 | NEVER ISSUED | | | | |
| 206-06-74-3 | Basic | 12-10-74 | | V | Hydraulic Pump and Reservoir Repair to Stop Fretting, Mandatory by 15 January 1975 |
| 206-08-74-1 | Basic | 3-25-74 | | VII | Oil Pressure Tube Assy., Mandatory Replacement by 1 July 1974 |
| 206-10-74-1 | Basic | 1-29-74 | | VII | Fuel Cell Cavity and Vent Line Modification |
| 206-10-74-2 | Basic Rev. A | 3-21-74 5-8-74 | | VII | Fuel Cavity Vent Line, Modification |
| 206-50-74-1 | Basic Rev. A | 9-17-74 10-29-74 | | S.I. | Rotor Brake Shock Mounted Disc Assy., Mandatory Removal by 30 September 1974 |
| 206-75-1 | Basic | 3-4-75 | | VI | Tail Rotor Drive Installation, Inspection of |
| 206-75-2 | Basic Rev. A | 2-18-75 4-16-75 | | IV | Tail Rotor Control Tube, Inspection Mandatory by 20 March 1975 |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | SUBJECT |
|---------------|-----------------|-------------------|---------------|-----------------|---|
| | | | | REF. | |
| 206-75-3 | Basic | 5-1-75 | | II | Main Rotor Hub Pillow Blocks Epoxy Resin Coated Flanged Bushings, Installation of |
| 206-75-4 | Basic | 5-15-75 | | III | Tail Rotor Yoke Retirement |
| 206-75-5 | Basic | 5-22-75 | | S.I. | Rework of External Hoist, Mandatory by 1 September 1975 |
| 206-75-6 | Basic Rev. B | 6-6-75 1-12-76 | | XI | Fuel Pump Circuit Capacitor, Removal of |
| 206-75-7 | Basic | 9-5-75 | | VIII | Passenger Door Hinge Rivets, Inspection of |
| 206-75-8 | Basic | 10-16-75 | | VII | Fuel Purge Line 10 Micron Filters, Installation of |
| 206-75-9 | Basic | 10-25-75 | | V | Hydraulic Pressure Regulator Valve, Modification of |
| 206-75-10 | Basic | 11-13-75 | | II | Main Rotor Blades, P/N 206-010-200-29, Mandatory Retirement of |
| 206-76-1 | Basic | 1-26-76 | | IV | Inspection of Hydraulic Servo Actuator Support Assembly, P/N 206-001-520-5, for Cracks in Forward Web |
| 206-76-2 | Basic | 2-6-76 | | II | Installation of Model 206L Main Rotor Split Cone Set, P/N 206-010-003-7, on Model 206B Helicopters |
| 206-76-3 | Basic | 4-20-76 | | VII | Inspection of Fuel System |
| 206-76-4 | Basic Rev. B | 5-7-76 7-8-76 | | II | Inspection of Main Rotor Hub Tension/Torsion Strap Assembly, P/N 206-010-105-3 |
| 206-76-5 | Basic | 5-12-76 | | V | Inspection of Hydraulic Servo Actuators, P/N 206-076-031-7 or -13 (H. R. No. 41000670-1, -003, or -005) |
| 206-76-6 | Basic | 6-16-76 | | VII | Linear Actuator, P/N 206-062-721-1 or -11 (Vendor P/N 7185-1) |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | SUBJECT |
|---------------|-----------------|--------------------|---------------|-----------------|--|
| | | | | REF. | |
| 206-76-7 | Basic Rev. A | 8-13-76 1-6-77 | | II | Reduction of Service Life, Tension/ Torsion Straps, P/N 206-010-105- 3. Replacement of Strap Fittings, P/N 206-010-155-11 and -15 |
| 206-76-8 | Basic Rev. A | 7-13-76 8-20-76 | | IV | Installation of Taper Washers Under Hydraulic Servo Actuator Support Assembly |
| 206-76-9 | Basic Rev A | 7-23-76 7-23-76 | | IV | Installation of Bearings, P/N 206- 040-339-9 |
| 206-76-10 | Basic Rev. B | 8-26-76 10-7-76 | | VIII | Replacement of Litter Door Post Striker Housing Assembly |
| 206-76-11 | Basic | 9-7-76 | | VI | Replacement of Collars, P/N 206- 040-319-3 and -5 |
| 206-76-12 | Basic Rev. A | 9-7-76 12-2-76 | | VI | Installation of Bearings, P/N 206- 040-339-9 |
| 206-77-1 | Basic | 3-15-77 | | II | Main Rotor Hubs P/N 206-010-100 and 206-011-100 (All Dash Numbers) |
| 206-77-2 | Basic | 3-22-77 | | S.I. | Rotor Brake Kits - Replacement of Lining Retention Screws |
| 206-77-3 | Basic | 4-1-77 | | VII | Inspection of Tube Assembly, P/N 206-061-541-1 or 206-061- 522-1, for Evidence of Chafing |
| 206-77-4 | Basic | 4-6-77 | | II | Reduction in Calendar Life, Tension/Torsion Straps, P/N 206-010-105-3 and -5 |
| 206-77-5 | Basic Rev. A | 5-12-77 5-16-77 | | VI | Inspection of Oil Cooler Blower Impeller, P/N 206-061-432-5 |
| 206B-77-6 | Basic | 6-20-77 | | VII | N ₂ Operating Speed Restriction |
| 206-77-7 | Basic | 10-10-77 | | II | Retirement Time and Calendar Life, Tension/Torsion Straps, P/N 206-010-105-3 and -5, and 206-011-147-1 |
| 206-77-8 | Basic | 10-20-77 | | B3: 66 | Inspection of Oil Cooler Blower Impeller, P/N 206-061-432-11 |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | SUBJECT |
|---------------|-----------------|---------------------|---------------|--------------------|---|
| | | | | REF. | |
| 206-77-9 | Basic | 10-21-77 | | A/B: VI | Replacement of Tail Rotor Drive Shaft Clamp Type Bearing Hangars With Shims |
| 206-77-10 | Basic Rev. A | 12-8-77 2-21-78 | | B3: 66 | Replacement of Oil Cooler Blower Impeller, P/N 206-061-432-11, With Impeller, P/N 206-061-432-31 |
| 206-78-1 | Basic | 4-14-78 | | A/B:II B3:65 | M/R Hub Tension Torsion Straps, P/N 206-010-105-3, -5, Retirement of |
| 206-78-2 | Basic | 12-18-78 | | B3: 66 | Freewheeling Outer Race Shaft, P/N 206-040-221-3, Inspection |
| 206-79-3 | Basic | 5-23-79 | | A/B: XII B3:97 | VOR Antenna P/N CI-159 and CI-159A |
| 206-79-4 | Basic | 7-17-79 | | A/B: II B3: 65 | Main Rotor Yoke, P/N 206-010-101 (All Dash Numbers), Inspection and Retirement Life of |
| 206-79-5 | Basic | 10-24-79 | | A/B: VI B3: 66 | 206 Main Input Driveshaft Assy, P/N 206-040-100-13, Inspection Interval of |
| 206-80-6 | Basic | 2-22-80 | | A/B: III B3: 65 | Tail Rotor Blade, P/N 206-010-750-005 and -007, Inspection of |
| 206-80-7 | Basic Rev. B | 2-26-80 10-15-80 | | A/B: 11 B3:65 | Main Rotor Trunnion, P/N 206-010-136-001, 206-010-136-003, and 206-011-113-001, Inspection Requirements |
| 206-80-8 | Basic | 4-11-80 | | A/B: IV B3:27 | Anti-Torque Control System Procedures |
| 206-80-9 | Basic | 6-3-80 | | A/B: II B3:65 | Addition of Calendar Life Retirement on TT Straps, P/N 206-011-147-001 and 206-011-147-005 |
| 206-80-10 | Basic | 6-4-80 | | A/B: VII B3:71 | Engine Lower Center Support Legs Acoustic Mounts, Modification of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | |
|---------------|-----------------|--------------------|---------------|--------------------|---|
| | | | | REF. | SUBJECT |
| 206-80-11 | Basic | 6-27-80 | | S.I. | External Hoist Kit, P/N 206-706-126-001, Mod and Inspection of (Inspect and Modify as Described in the Attached Breeze Corp. Bulletin No. BEB-162-8) |
| 206-80-12 | Basic | 9-9-80 | | A/B: III B3: 65 | Aluminum Tail Rotor Blade, P/N 206-010-750-005 and -007, Retirement and Replacement of |
| 206-81-13 | Basic | 4-24-81 | | S.I. | Stability and Control Augmentation System (SCAS) Anti-Torque Cylinder Assembly, Inspection and Rigging of |
| 206-81-14 | Basic | 6-22-81 | | A/B: VII B3:71 | Engine, Allison 250-C20/C20B, N1 and N2 Operating Speed Restrictions |
| 206-81-15 | Basic Rev. A | 8-21-81 9-28-81 | | S.I. | External Hoist and Hoist Provision Kits, P/N 206-706-124-001/003, 206-706-126-001/003, Addition of Ground to Hoist Assy. and Route Shield Through Electrical Connector on |
| 206-82-16 | Basic | 5-19-82 | | A/B: III B3:65 | Tail Rotor Blade, P/N 206-016-201-001 and 206-016-201-103, Check and Repair of |
| 206-82-17 | Basic | 5-28-82 | | S.I. | Skid Mounted, Light-Weight Emergency Flotation System Kit, P/N 206-706-211-101 and -103, Float Restraint Tubes, P/N 206-050-269-101, Addition of |
| 206-82-18 | Basic | 7-19-82 | | B3: 28 | Fuel Shutoff Valve, Provision for Thermal Relief |
| 206-82-19 | Basic | 11-15-82 | | A/B: VI B3: 66 | Tail Rotor Gearbox P/N 206-040-400 (All Dash Numbers), Inspection of |
| 206-83-20 | Basic | 8-29-83 | | S.I. | External Hoist Kits, P/N 206-706-126-1/-5/-101/-103, Hoist P/N BL-16600 (All Dash Numbers), Conversion and Inspection of |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | SUBJECT |
|---------------|-----------------|---------------------|---------------|--------------------|--|
| | | | | REF. | |
| 206-83-21 | Basic Rev. A | 12-22-83 2-29-84 | | A/B: VI B3: 66 | Mast Assembly, Main Rotor, P/N 206-010-332, Inspection and Processing of |
| 206-84-22 | Basic | 1-4-84 | | B3: 28 | Fuel Supply Tube Assembly, P/N 206-061-452-101, Replacement of |
| 206-84-23 | Basic | 1-24-84 | | S.I. | Emergency Flotation Kit Reservoir and Piping Installation, P/N 206-073-801-001, Clamps, P/N MS 21920-53, Replacement |
| 206-84-24 | Basic | 8-30-84 | | S.I. | Reservoir, Emergency Flotation, P/N 274645, 206-073-919-001, 206-073-919-003, 206-073-919- 005, 206-073-919-007, Installation of Decal (WARNING), P/N 31-023- 8B, Decal (CAUTION), P/N 31-023-9B, On |
| 206-84-25 | Basic | 8-30-84 | | S.I. | Reservoir, Emergency Flotation, P/N 1269556-4, Installation of Decal (WARNING), P/N 31-023- 8B, and Decal (CAUTION), P/N 31-023-9B, On |
| 206-84-26 | Basic | 8-30-84 | | S.I. | Reservoir, Emergency Flotation, P/N 206-073-922-1, -101, 206- 073-919-1, -3, -5, -7, Installation of Decal (WARNING), P/N 31-023- 8B, and Decal (CAUTION), P/N 31-023-9B, On |
| 206-85-27 | Basic Rev. A | 2-13-85 3-15-85 | | S.I. | Quick Disconnect Dual Controls P/N 206-706-127-1, -101, -109, Installation of Spring Pin Assembly |
| 206-85-28 | Basic Rev. B | 3-7-85 6-21-85 | | A/B: III B3: 65 | Tail Rotor Blade, P/N 206-016-201- 001/-103/-107, Check and Rivet Replacement |
| 206-85-29 | Basic | 6-21-85 | | A/B: IV B3:27 | Cyclic Control Stick Assembly, P/N 206-001-334-1/-101, and 206- 001-381-7, Inspection of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | |
|---------------|-----------------|---------------------|---------------|--------------------|--|
| | | | | REF. | SUBJECT |
| 206-85-30 | Basic Rev. B | 9-30-85 10-13-86 | | S.I. | External Hoist Kits, P/N 206-706-126-1/-5/-101/-103, Conversion of Hoist P/N BL-16600-80 to P/N BL-16600-110 |
| 206-86-31 | Basic | 3-24-86 | | A/B: IV | Tail Rotor Crosshead, P/N 206-011-857-001, Installation of |
| 206-86-32 | Basic | 3-27-86 | | A/B: X B3: 95 | 206-070-263-005 Altimeter, Malfunction of Setting Knob Mechanism |
| 206-86-33 | Basic | 8-13-86 | | A/B: VI B3: 66 | Oil Cooler Blower Impeller P/N 206-061-432-031, Inspection of |
| 206-86-34 | Basic Rev. A | 9-30-86 10-23-86 | | A/B: VII B3: 28 | Airframe Fuel Filter Assembly P/N 222366-621-003 and P/N 52-2889-016 or -016A, Modification of |
| 206-87-35 | Basic | 1-19-87 | | S.I. | Reservoir Assembly, P/N 206-073-848-103/-105/-109, Valve Assembly, P/N 206-073-915-005/-101, Cap, Replacement of |
| 206-87-36 | Basic Rev. A | 1-28-87 6-17-87 | | S.I. | Rescue Hoist Cable Cutter Circuit, Rewiring of, In Accordance with Breeze Manufacturing Preferred Method |
| 206-87-37 | Basic | 4-23-87 | | A/B: VI B3: 66 | Main Rotor Mast, P/N 206-010-332-121, Return for Metallurgical Evaluation |
| 206-87-38 | Basic | 5-26-87 | | - | Wire Strike Protection System, Inspection and Rework of |
| 206-87-39 | Basic | 9-17-87 | | A/B: IV B3: 65 | Tail Rotor Pitch Link(s), P/N 206-010-793-101, Inspection of |
| 206-87-40 | Basic Rev. A | 10-8-87 11-3-87 | | A/B: VII B3: 28 | Engine Fuel Valve Electrical Connector, P/N 3456W14S-5S, One Time Inspection of |
| 206-88-41 | Basic | 1-28-88 | | A/B: III B3: 65 | Tail Rotor Yoke, P/N 206-011-819-101, Return for Inspection and Rework |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | |
|-----------|-----------------|----------------------|--------|--------------------|--|
| | | | | REF. | SUBJECT |
| 206-88-42 | Basic Rev. A | 7-26-88 8-26-88 | | S.I. | External Hoist, P/N BL-16600-(All Dash Numbers), Inspection of Load Cable and Hook/Bumper Stowage |
| 206-89-43 | Basic Rev. A | 1-10-89 8-1-89 | | A/B: VII B3: 79 | Aeroquip 601 Hose Assemblies, One-Time Inspection and Replacement |
| 206-89-44 | Basic | 3-21-89 | | A/B: VII B3: 71 | Pc Air Filter Housing Assembly, Replacement of |
| 206-89-45 | Basic Rev. B | 4-11-89 7-28-92 | | A/B: VII | Bendix Power Turbine Governor Py Port, Inspection of |
| 206-89-46 | Basic Rev. A | 8-2-89 8-29-89 | | A/B: II B3: 65 | Strap Assembly, Main Rotor, Tension-Torsion P/N 206-011-147-7 and P/N 206-011-154-101/-105, Removal from Service |
| 206-89-47 | Basic Rev. A | 8-20-89 8-29-89 | | A/B: III B3: 65 | Tail Rotor Hub Assembly P/N 206-011-810-015 and Tail Rotor Yoke P/N 206-011-811-009, Removal from Service |
| 206-89-48 | Basic | 9-21-89 | | A/B: II B3: 65 | Main Rotor Flight Control System Bolts, Inspection of |
| 206-89-49 | Basic | 10-10-89 | | S.I. | Emergency Float Bag Inflation Valve Restrictors-Installation of, (Service Instruction 206-115) |
| 206-89-50 | Basic Rev. A | 10-25-89 11-29-89 | | A/B: II | Main Rotor Blade P/N 206-010-200-033, Removal from Service |
| 206-89-51 | Basic Rev. B | 10-29-89 2-5-90 | | S.I. | Breeze-Eastern Cargo Hooks P/N SP4232-5, -31 and 14027-2, Warning Plate, Addition of |
| 206-90-52 | Basic Rev. B | 2-23-90 3-5-92 | | A/B: IV | Tail Rotor Control Tube-Inspection For Possible Interference of |
| 206-90-53 | Basic | 5-15-90 | | A/B:XII B3: 97 | VOR Antenna P/N CI-259D Date Coded D/M 8930 to D/M 9015 Inclusive |
| 206-90-54 | Basic | 5-31-90 | | A/B: XI B3:96 | Fuel Valve Switch Guard, Installation of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP | |
|---------------|-----------------|----------------------|---------------|---------------------|---|
| | | | | REF. | SUBJECT |
| 206-90-55 | Basic Rev. A | 6-12-90 7-16-90 | | A/B:VII B3:71 | Turbine Spline Adapter, Replacement of |
| 206-90-56 | Basic Rev. A | 6-21-90 1-15-91 | | A/B: VI B3: 66 | Sungear P/N 206-040-662-101, Recall of by Serial Number |
| 206-90-57 | Basic | 6-27-90 | | A/B: III B3: 65 | Tail Rotor Blade P/N 206-016-201- 113 and 206-016-201-127, Inspection of |
| 206-90-58 | Basic Rev. A | 9-18-90 10-31-90 | | A/B: III B3: 65 | Tail Rotor Blade 206-016-201-125/ -127, Removal From Service |
| 206-91-59 | Basic | 1-30-91 | | A/B: VI | Bearing Hanger, 206-040-346 One Time Insp. |
| 206-91-60 | Basic | 6-28-91 | | A/B: VII B3: 53 | PART I: Vertical Fin Supports P/N 206-031-417 and 206-031- 418, Inspection and Modification of PART II: Vertical Fin Assembly P/N 206-020-113-5, -7, -9, -107 Inspection for Gaps and Addition of Mounting Spacers, if Required |
| 206-91-61 | Basic | 9-13-91 | | A/B: VI B3:66 | Driveshaft Seal Assembly 206-040-272-101, Replacement of |
| 206-91-62 | Basic | 9-19-91 | | A/B: VIII B3: 25 | Restraint Assembly 222-320-823- 109, -111, Improvement of |
| 206-91-63 | Basic Rev. A | 10-10-91 10-31-91 | | A/B: VII B3:76 | Possible Incorrect Max Fuel Flow Setting on Certain Bendix Fuel Controls |
| 206-91-64 | Basic | 11-21-91 | | A/B: VIII B3: 53 | Horizontal Stabilizer Spare Assembly P/N 206-020-120-011, Removal From Service |
| 206-91-65 | Basic | 11-26-91 | | A/B: VII 83:71 | Engine Bleed Valve, Removal From Service |
| 206-92-66 | Basic | 5-5-92 | | | Main Rotor Pillow Block Retention Hardware, Replacement of Bolt MS21250-04018 |
| 206-92-67 | Basic | 5-7-92 | | | Tail Rotor Gearbox Oil Level Indicators 204-040-508-001 and 204-040-508-011 |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------------|-----------------|--------------------|---------------|--------------------------|--|
| 206-92-68 | Basic | 8-5-92 | | | Flap Restraint 206-011-117-003 |
| 206-92-69 | Basic Rev. A | 9-29-92 2-27-95 | | | Bracket, Bearing Support 206-030-407-007/-009 and 206- 030-433-005/-007/-011/-013/-015 and -017, One Time Inspection |
| 206-92-70 | Basic | 12-3-92 | | | Main Rotor Latch Bolt 206-011- 260-101 and -103, Removal of Unapproved Bolts From Service |
| 206-92-71 | Basic | 12-8-92 | | | Fuel Quantity Probes 7740-00381 and 7740-00302, One Time Inspection |
| 206-92-72 | Basic | 12-14-92 | | | Torque Transducer 206-061-535- 005-011, -013, Replacement of |
| 206-93-73 | Basic Rev. A | 6-21-93 6-20-94 | | | Cargo Hook, Breeze Eastern Customer Advisory Bulletin No. CAB-100-41 and Customer Service Bulletin No. CSB-143 and CSB-144 |
| 206-93-74 | Basic Rev. B | 9-7-93 4-4-94 | | | Swashplate Support Assembly 206-010-452-001/-005/-109, Inspection of |
| 206-93-75 | Basic | 10-19-93 | | | Trunnion 206-011-113-103 Master Spline Mislocation of |
| 206-93-76 | Basic Rev. B | 12-7-93 9-6-94 | | | Main Driveshaft Grease Lubricated Couplings 206-040-108 and 206- 040-118, Over-Temperature Indicators, Installation of |
| 206-93-77 | Basic | 11-17-93 | | | Main Rotor Blade 206-010-200- 133 Inspection and Rework |
| 206-94-78 | Basic | 4-11-94 | | | Landing Gear Assembly Improve- ment: Crosstube Assemblies, Replacement of and Skid Tube Assemblies, Modification of |
| 206-94-79 | Basic | 5-5-94 | | | Tail Rotor Pitch Horn 206-011-809- 005/-107/-109, Looseness Check of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------------|-----------------|---------------------|---------------|--------------------------|---|
| 206-94-80 | Basic | 8-2-94 | | | Main Rotor Trunnion 206-011-113-103, Removal From Service |
| 206-94-81 | Basic Rev. A | 8-17-94 11-1-95 | | | Landing Gear Assembly Improvement; Fixed Floats Kit P/N 206-706-008-013, Crosstube Assemblies P/N 206-050-169-001/-003, Replacement of |
| 206-94-82 | Basic Rev. A | 9-6-94 4-17-95 | | | Landing Gear Assembly Improvement; Emergency Flotation System Kit P/N 206-706-010, Crosstube Assemblies P/N 206-050-134-001, -007, -103, -003, -005, -011 and -105, Replacement of |
| 206-94-83 | Basic | 9-6-94 | | | Landing Gear Assembly Improvement Emergency Lightweight Float Kit P/N 206-706-211, Crosstube Assemblies P/N 206-050-107-25, -27, -119 and -121, Replacement of Skid Tube Assemblies P/N 206-050-246-ALL Dash Numbers, Modification of and Step Assemblies, P/N 206-050-259, Modification of |
| 206-95-84 | Basic | 7-24-95 | | | Hydraulic Servo Actuators (HR Textron) Shoulder Bolts, One Time Inspection of |
| 206-95-85 | Basic | 9-5-95 | | | Main Drive Shaft 206-040-015-103 Inner Coupling to Shaft Attachment Hardware, One Time Inspection of |
| 206-95-86 | Basic Rev. B | 9-11-95 12-18-95 | | | Tail Rotor Driveshaft Hanger Assembly and Spring, Inspection of |
| 206-96-87 | Basic Rev. A | 2-26-96 3-22-96 | | | Cyclic and Collective Servo Support Assembly P/N 206-001-566-105, Identification of |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------------|-----------------|----------------------|---------------|--------------------------|---|
| 206-96-88 | Basic | 6-3-96 | | | Landing Gear Assembly Improvement; Fixed Float Kit P/N 206-706-008-011; Crosstube Assemblies P/N 206-050-157-001 & -003, Replacement of |
| 206-97-89 | Basic | 5-20-97 | | | R-134a Air Conditioning System Installation Hardware, Replacement of |
| 206-97-90 | Basic | 6-20-97 | | | Main Rotor Hub Pillow Block, Change in Retention Hardware |
| 206-97-91 | Basic | 10-10-97 | | | Engine Driven Fuel Pump (CECO), Internal Drive Spline, Inspection of |
| 206-98-92 | Basic Rev. A | 10-14-98 10-10-02 | | | Engine Fuel Control Unit, Internal Spring Replacement |
| 206-00-93 | Basic Rev. A | 3-10-00 5-10-00 | | | Collective Lever Assembly 206-010-467-001, Modification and New Collective Lever Assembly/-105, Introduction of |
| 206B1-01-94 | Basic | 1-19-01 | | | Magnetic Brake P/N 204-001-376-003, One Time Inspection of |
| 206-01-95 | Basic | 3-6-01 | | | Rescue Hoist, BL-16600 Series, Breeze Eastern Customer Alert Bulletin CAB-100-58 |
| 206-01-96 | Basic Rev. A | 3-30-01 5-7-01 | | | Chip Detector Assembly, Tedeco B3188B |
| 206-01-97 | Basic | 7-26-01 | | | Strap Fittings P/N 206-011-140-001, Tail Rotor Gearbox Input Pinions, P/N 206-040-405-101, Inspection and Recall of Specific Serial Number Part |
| 206-01-98 | Basic | 10-11-01 | | | Rolls Royce Engine, Gearbox Assembly – Inspection of Helical Torquemeter Gearshaft Assembly |
| 206-02-99 | Basic Rev. A | 11-26-02 1-31-03 | | | Main Rotor Blades 206-010-200-ALL Inspection and Rework of |

BHT-206A/B/B3-ASB INDEX**206A/B/B3 ALERT SERVICE BULLETIN INDEX**

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------------|-----------------|--------------------|---------------|--------------------------|--|
| 206-04-100 | Basic Rev. C | 3-12-04 3-22-05 | | | Tail Rotor Blades 206-016-201-133/-131 Check/Inspection of |
| 206-04-101 | Basic | 9-13-04 | | | Tail Rotor Blade 206-016-201-131, Check and Removal from Service of |
| 206-04-102 | Basic | 9-24-04 | | | Inside Door Handle Assembly P/N 206-031-620-101, Inspection and Rework of |
| 206-05-103 | Basic Rev. A | 2-15-05 7-12-06 | | | Fuel Distribution System, Inspection and Rework of |
| 206-05-104 | Basic | 5-17-05 | | | Torque Indicator 206-075-739-125, Recall of |
| 206-05-105 | Basic | 11-8-05 | | | Tail Rotor Trunnion Housing Seal 535642 Installation, One Time Inspection of |
| 206-06-106 | Basic | 2-17-06 | | | Float Inflation Valve Squib P/N 29022968, Misidentification of |
| 206-06-107 | Basic Rev. A | 4-26-06 6-15-06 | | | Vertical Fin Supports 206-031-417-003/-007 and 206-031-418-001/-005, Inspection of |
| 206-06-108 | Basic | 7-8-06 | | | Aeronautical Accessories Inc. Flat Crew Door Window P/N 206-202-001 and 206-202-002, STC SH5773SW |
| 206-06-109 | Basic | 7-25-06 | | | Main Rotor Latch Bolts 206-010-169-001/-003 and 206-011-122-003, Removal from Service of |
| 206-06-110 | Basic | 9-7-06 | | | Upper Left-hand Tailboom Attachment Hardware, Inspection of |
| 206-06-111 | Basic | 10-12-06 | | | Engine, Turbine Assembly — Power Turbine Outer Shaft |

206A/B/B3 ALERT SERVICE BULLETIN INDEX

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------------|----------------|--------------------|---------------|--------------------------|---|
| 206-07-112 | Basic | 3-9-07 | | | Aeronautical Accessories, Inc. PC Safety Valve™ Stem Over Torque STC SE5511NM |
| 206-07-113 | Basic | 3-23-07 | | | Cargo Hook Stress Corrosion Cracks |
| 206-07-114 | Basic | 3-28-07 | | | Disc Assembly P/N 32721-1, Inspection of |
| 206-07-115 | Basic | 5-21-07 | | | Power Turbine RPM (N2) Steady State Operation Avoidance, Introduction of |
| 206-07-116 | Basic Rev A | 9-11-07 9-19-07 | | | Tail Rotor Blade Assembly, Inspection of |

NOTICE

The following blank pages are provided for entry of additional bulletins when distributed. These additional bulletins will be included in this index at next revision.

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|---------------|--------------|-------------|---------------|--------------------------|----------------|
|---------------|--------------|-------------|---------------|--------------------------|----------------|

BHT-206A/B/B3-ASB INDEX

NOTICE

The following blank pages are provided for entry of additional bulletins when distributed. These additional bulletins will be included in this index at next revision.

| NUMBER | ISSUE | DATE | STATUS | ATA/CHAP REF. | SUBJECT |
|--------|-------|------|--------|------------------|---------|
|--------|-------|------|--------|------------------|---------|